

## Wireless Accessories

### DX Series (DX100, 121, 210, 300ES, 410)

#### Batteries and Chargers

For use with:

BP200  
BP210  
BP300



BAT41



AC40A Battery Charger  
Order #104034

For use with:

BP410  
WH220  
WH301  
WH410



BAT50  
Order #CZ-BAT50



AC50 Battery Charger  
Order #CZ-AC50-US (USA)  
Order #CZ-AC50-WW (Worldwide)  
Order #CZ-AC50-KR (Korea)

For use with:

MB100



BAT850  
Order #G27021-1



AC850A Battery Charger  
Order #G28820-1Z1

#### Power Supplies



For AC40A and all DX base stations



For AC50 US/Canada  
Order #Atn: 453G013



For AC50 Worldwide

#### Miscellaneous Accessories



DX Base Antenna  
Order #101G048



DX Antenna Splitter/Combiner  
Order #647G006



DX Beltpack Pouch  
Order #107G065



1RU Antenna Mounting Kit  
Order #G28066-1



CAT-5 Cable  
Order #115G372