

# Camera Adapter with Shoe Mount



CM03 / 14722



## Features and Benefits

The CM03 Camera Adapter with Shoe Mount attaches to a wide range of photo and video accessories to a camera. The base slides into a camera shoe or can be removed to screw onto a tripod or lighting stand while the top holds devices such as lights, flashes, and other accessories. For precise positioning of accessories, the ball joint tilts 180 degrees and pans 360 degrees. Whether mounting a light to a camera's shoe or mounting a small, lightweight camera to a lighting stand, this adapter is up to the task.

## Specifications

**Application:** Photo and video accessory mounting

**Male Threading at Top:** 1/4" -20

**Base Plate:** Standard hot shoe mount

**Female Threading at Bottom (with shoe removed):**  
1/4" -20

**Ball-Joint Pan Adjustment:** 360°

**Weight Capacity:** 3.5 lb

**Color:** Black

